

All products are trademarks of Nostalgia Products Group, LLC. Worldwide design & utility patented or patents pending. © 2013 Nostalgia Products Group, LLC.

www.nostalgiaelectrics.com

(rev. 06/28/13)





BPC700 RETROREI

## **Retro Series Beverage Party Cooler**

Instruction Manual



## Make every day a party! Visit www.nostalgiaelectrics.com for more fun products.

## **CONTENTS**

IMPORTANT PRECAUTIONS	3
IMPORTANT SAFEGUARDS	3
INTRODUCTION	5
PARTS & ASSEMBLY	6
HOW TO OPERATE	7
HELPFUL TIPS	.8
CLEANING & MAINTENANCE	.8
RETURNS & WARRANTY	9

## **SAFETY**

Your safety and the safety of others is very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

#### **Appliance Specifications:**

115 Volts, 60 Hertz 85 Watts, UL Approved

## IMPORTANT PRECAUTIONS

- 1. NEVER immerse appliance in water.
- 2. NEVER use near water.
- 3. NEVER use an abrasive sponge or cloth on the appliance.
- 4. NEVER leave appliance unattended while in use.
- 5. NEVER place anything other than foods and beverages in the appliance.
- 6. Unplug unit from outlet when not in use and during cleaning.
- DO NOT operate this appliance with a damaged cord or plug, nor if the appliance ever malfunctions.
- 8. Keep out of reach of children.
- 9. This appliance is NOT A TOY.
- Unsupervised young children and cognitively challenged individuals should never operate this appliance.
- 11. Young children should be supervised while in proximity of the appliance to ensure that they do not play with it.

## IMPORTANT SAFEGUARDS

Basic safety precautions should always be followed when using electrical appliances, including the following:

- 1. Read all instructions before operating this appliance.
- 2. To protect against electrical shock do not immerse cord, plug or any part of this appliance in water or other liquids.
- 3. Close supervision is necessary when any appliance is used near children.
- 4. Children should be supervised to ensure that they do not play with the appliance.
- This appliance is not intended for use by children, cognitively, or physically challenged individuals, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- 6. Unplug from outlet when not in use, before removing parts and before cleaning.
- DO NOT operate any appliance with a damaged cord or plug, nor if the appliance has been damaged in any manner. Return the appliance to the nearest repair shop for examination or repair.
- 8. DO NOT operate this appliance in the presence of explosive fumes.
- The manufacturer does not recommend the use of accessory attachments. Use of accessory attachments may cause injuries.
- 10. DO NOT use near water, including bathtubs, showers or swimming pools.
- 11. DO NOT place on or near a hot gas or electric burner, nor in a heated oven.
- 12. Extreme caution must be used when moving this appliance.
- 13. DO NOT use the appliance for other than its intended use.

- 14. Check appliance for presence of foreign objects prior to use.
- 15. NEVER put anything living into the appliance for risk of severe injury or death.
- 16. DO NOT cover or block any ventilation openings on the appliance.
- 17. DO NOT expose the cooler to direct sun or rain.
- DO NOT use the cooler outdoors for a prolonged period of time. Store the unit indoors when not in use.
- 19. A short power supply cord is provided to reduce the risk resulting from becoming entangled or tripping over a long cord.
- 20. Longer detachable power supply cords can be used if care is exercised in their use.
- 21. DO NOT let cord hang over the edge of a table or countertop.
- 22. The marked electrical rating of an extension cord should be at least as great as the electrical rating of the appliance.
- 23. This appliance has a three-pronged plug. To reduce the risk of electrical shock, this plug is intended to fit into an outlet only one way. Do not modify the plug in any way. This appliance must be grounded. Connect only to properly grounded outlet.
- The voltage and frequency of this product should be 120V, 60Hz.
   Contact an authorized service technician if the wire is damaged.
- DO NOT interrupt the power by pulling the power supply cord and/ or pulling the power plug out of its socket directly.
- 26. DO NOT damage the refrigerant circuit.
- 27. All maintenance on this unit should be done by an authorized repair technician.
- 28. DO NOT store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- 29. This appliance is intended for household use and similar uses such as:
  - Staff kitchen areas in shops, offices and other working environments
  - Farm houses and by clients in hotels, motels, bed and breakfasts and other residential environments
  - · Catering and similar non-retail applications
- 30.

**DANGER! RISK OF CHILD ENTRAPMENT!** Before you throw away your cooler, **REMOVE THE COVER!** Leave the shelves in a place so that children may not easily climb inside.

- 31. DO NOT dispose of this product as unsorted municipal waste. Collection of such waste separately, for special treatment, is necessary.
- 32. It is best to not store objects on top of this appliance which are magnetic, heavy or filled with water or other liquids. Electronic components may not work if water gets inside of this appliance. Do not store valuable objects, objects that are adversely affected by temperature or serum, bacterin, etc. inside or on top of the appliance.

## 33. 🛕

#### **SPECIAL SAFETY NOTICE:**

- If gas leaks from its container, don't pull the plug out or in, as it may cause sparks or fire.
- Don't splash water on the back of the appliance, as it may cause malfunction or electric shock.
- Don't store flammable materials such as ether, benzene, gas and glue in the cooler.

# SAVE THESE INSTRUCTIONS! INTRODUCTION

Thank you for purchasing the BEVERAGE PARTY COOLER from Nostalgia Electrics™!

This large capacity cooler keeps up to 60 12-oz. cans of everyone's favorite beverages perfectly chilled and easy to access. Best of all, there's no need for ice, keeping bottles and cans dry and drip free. Set atop sturdy casters, this portable unit goes wherever you need it, including backyard barbecues, tailgating and other special gatherings.

#### Features include:


- Adjustable thermostat
- Transparent lid
- · Two interior removable shelves
- · Rolling casters for easy mobility

#### **SPECIFICATIONS AND PARAMETERS**

- Current: 1.7 A
- Rated Voltage: 115 V
- Rated Frequency: 60Hz
- Temperature: 39 61 degrees F
- Standby Cooling Time: 5 10 hours
- Dimensions:Diameter = 20" Height = 32.5"
- Weight: 59.5 lbs.

## **PARTS & ASSEMBLY**

Your BEVERAGE PARTY COOLER requires very little assembly. Before using, remove all packing materials from inside the cooler.



#### **PARTS**

- 1. Transparent removable lid
- 2. Digital Temperature Control
- 3. Ball Bearing Casters
- 4. Removable Basket Shelves (inside)

#### THERMOSTAT CONTROL



## **HOW TO OPERATE**

Before first use, clean the inside of the BEVERAGE PARTY COOLER using a non-abrasive sponge or cloth and lukewarm water mixed with a mild detergent. Dry thoroughly prior to use.

#### INSTALLATION

- The cooler should be placed on a completely flat surface.
   Allow 1 foot of space on all sides of the cooler.
- Choose a location for your cooler that is not exposed to direct sunlight, high temperature or humidity, or rain. DO NOT operate the cooler near water or swimming pools.
- The surface of the location where the cooler is installed should be firm and flat. If cooler is not secured in a proper location, noise and vibration may occur. The refrigeration system of the cabinet is designed to operate with the cabinet located on a flat surface. DO NOT tilt the cabinet to the side.
- 4. If the cabinet must be tilted on an angle for handling or moving purposes, allow it to sit in an upright position 20 to 30 minutes prior to plugging it in and starting the cooling of the storage compartment.

#### **OPERATING THE COOLER**

- 1. Insert power plug into wall outlet.
- 2. Press power button on front (right of digital display) to turn on the refrigeration system.
- Press the thermostat button on the front (left of the digital display) to adjust the desired temperature for the refrigeration system. The temperature will increase 1 degree F per each press. The display will flash during the adjustment.
- To adjust the temperature down, press the right power button.
   The temperature will decrease 1 degree F per each press.
- 5. During normal use, the display will show the average temperature inside the cooler.
- The thermostat ranges from 39 61 degrees F. During normal use, the display will show the average temperature inside the cooler.

#### **SUGGESTED TEMPERATURES:**

- · Bottled water, soda or beer: 39 degrees F
- White wine: 45 50 degrees F
  Red wine: 55 61 degrees F
- When using the BEVERAGE PARTY COOLER for the first time, allow the unit to operate continuously for 12 - 18 hours.
- 8. Alternate the racks within the cooler every 6 hours to improve cooling.
- There should always be some space between items inside for air circulation. DO NOT fill with liquids, as there is no drainage hole.
- 10. Beverages should be kept in sealed containers to avoid spilling.
- 11. Reducing the frequency of opening the cover can lower the electronic consumption.

**NOTE:** Do not use any electronic equipment inside the appliance.

#### MOVING

The rolling casters make transporting the BEVERAGE PARTY COOLER easy. When moving, do not tilt appliance more than 45 degrees. Be very careful not to bump the cooler into anything.

## **HELPFUL TIPS**

The cooler does not work.

It may not be properly connected to the power supply, or the voltage may be too low.

The cooler does not work as efficiently as expected.

It may be caused by high outdoor temperatures, the thermostat setting being too warm, or by frequently opening and closing the lid.

It makes strange noises.

The noises may be caused by the cooler not being stabilized. Make sure the surface that the cooler is on is flat and firm.

• The inside of the cooler develops mold during storage.

When the BEVERAGE PARTY COOLER is not in use, the inside must be COMPLETELY DRY in order to avoid mold growth. Be sure to wipe the interior with a dry, non-abrasive cloth before storing. It is also best to store the unit without the lid in place.

## **CLEANING & MAINTENANCE**

To prolong the life of your BEVERAGE PARTY COOLER, please follow these simple instructions for maintenance. This appliance should be maintained and cleaned after each use.



To avoid electric shock, always unplug the cooler before cleaning or moving.

- Remove the contents inside the BEVERAGE PARTY COOLER.
- Wipe the interior surfaces with a damp non-abrasive cloth or sponge. You may use vinegar mixed with lukewarm water to prevent the growth of mold and fungus.
- 3. Wipe the outside of the cooler with a dry, non-abrasive cloth or towel.
- 4. Wash the lid in warm, soapy water with a non-abrasive cloth or sponge.
- DO NOT use harsh chemicals, abrasive cleaners or scouring pads on the BEVERAGE PARTY COOLER as they may damage the unit.
- 6. Thoroughly dry the interior, exterior and all parts after cleaning with a non-abrasive cloth.
- 7. Store the BEVERAGE PARTY COOLER in a clean, dry location when not in use.

## **RETURNS & WARRANTY**

SHOULD YOUR UNIT NOT WORK OR IF DAMAGED WHEN YOU FIRST TAKE IT OUT OF THE BOX, PLEASE RETURN IT TO THE PLACE OF PURCHASE IMMEDIATELY.

#### **RETRO SERIES BEVERAGE PARTY COOLER / BPC700**

Should you have any questions, please contact us via email or at the customer service number listed below between the hours of 8:00 AM and 5:00 PM, Monday through Friday, Central Standard Time.

#### Distributed by:

Nostalgia Products Group LLC 1471 Partnership Dr. Green Bay, WI 54304-5685 Customer Service Phone: (920) 347-9122

Phone: (920) 347-9122

Web: www.nostalgiaelectrics.com

#### **Customer Service Inquiry**

To submit a Customer Service inquiry, go to www.nostalgiaelectrics.com and fill out the Customer Service Inquiry form and click the Submit button.

A representative will contact you as soon as possible.

This appliance is designed and built to provide many years of satisfactory performance under normal household use. The distributor pledges to the original owner that should there be any defects in material or workmanship during the first 90 days of purchase, we will repair or replace the unit at our option. Our pledge does not apply to damages caused by shipping, mishandling or unit being dropped. A product deemed defective either from manufacturing or being mishandled is up to the distributor's discretion. In order to obtain service under this warranty, please contact Nostalgia Products Group, LLC at the telephone number listed above or by filling out the Customer Service Inquiry Form located at www.nostalgiaelectrics.com.

This product is not recommended for use outside of North America. The warranty is void if products are exported outside of the USA, Canada or Mexico.

#### This warranty does not apply to re-manufactured merchandise.

Please read these instructions carefully. Failure to comply with these instructions, damages caused by improper replacement parts, abuse or misuse will void this pledge to you and is being made in place of all other expressed warranties.

For more information, visit us online at www.nostalgiaelectrics.com.

Like us on Facebook at www.facebook.com/NostalgiaElectrics.
Follow our boards on Pinterest at www.pinterest.com/nostalgiaelctrx.
Tweet along with us on Twitter at www.twitter.com/NostalgiaElctrx.

